

SGK50 S2

SKILLER



Specifications

General


Т уре	Gaming Keyboard
Switch Technology	Hot-Swap (Gateron G Pro 3.0 Yellow)
Number of Keys	100 ANSI / 101 ISO
Keycap Material	PBT
Keycap Legend	Dye Sub
Illumination	RGB
Adjustable Illumination	✓
Lighting Effects	✓
Max. Polling Rate	1,000 Hz
Form Factor	96 % Layout
Onboard Memory for Game Profiles	✓
Capacity of Onboard Memory	256 kB
Detachable Cable	✓
■ Weight without Cable	1,023 g
■ Weight incl. Cable	953 g
Dimensions (L x W x H)	368 x 121 x 100 mm
Supported Operating Systems	Windows
Key Properties	
N-Key Rollover Support	✓
On-The-Fly Macro Recording	✓
Operating Force	50 ± 15 g
Switch Properties	Linear
Distance to Actuation Point	2.0 ± 0.6 mm
Operating Life Cycles of Keys	Min. 100 Million Keystrokes
Cable and Connectors	
Connector	USB Type-C
Textile-Braided Cable	✓
Coiled Cable	✓
Cable Length	150 cm
Gold-Plated USB Plug	✓
Package Contents	
SKILLER SGK50 S2 PBT, Keycap Puller Tool,	Switch Puller Tool, USB Cable (150 cm)
	,

VIA/QMK



If VIA configuration is not possible through the website at https://usevia.app/, please then use the alternative website at https://via.evove.top/.

Macro Keys




Record Macros

To record macros, first press and hold down the function key and then press the tab key. Once you have done this, the macro keys F9–F10 will start flashing. Press and hold down the function key and press one of these two macro keys to select it for macro recording. In the next step, first press and hold down the function key and then press Caps Lock key. The macro key you selected will now start to light up continuously. You can now start entering your macro actions. You can enter up to 16 individual actions. When you have reached the maximum number of actions, the selected macro key starts to flash and the recording is automatically ended. However, if you would like to end the recording before all 16 available macro actions have been entered, first press and hold down the function key and then press the Caps Lock key to end the recording.


Lighting Effects








Additional Functions




Remove Keycaps




Before removing a switch, first remove the keycap. To do this, place the arms of the keycap puller tool either to the left and right or to the top and bottom of the keycap, and then pull the keycap upwards with careful but constant pressure. Whenever possible, avoid pulling the keycaps from the switch directly with your fingers, as this may damage the switch.

Remove Switches



Once you have removed the keycap from the switch, position the switch puller tool correctly on the tabs of the switch. These are positioned to the front and the back of the switch. Before pulling out the switch, make sure that both tabs are securely pressed with the switch puller tool and that the switch can be removed from the socket without resistance. If necessary, remove the adjacent keycaps to allow the switch puller tool sufficient freedom of movement. After you have removed the keycap, press both tabs of the switch with the switch puller tool and then slowly pull the switch out of the socket. Be sure to always pull vertically from the socket with a straight, upward direction. Avoid pulling in a slanted direction, as this can result in damage.

Install Switches



To install the switches, position the switch so that one tab is at the front and the other tab is at the back. Each pin on the underside of the switch should be pointing exactly to its relevant contact in the keyboard socket. Make sure that the switch is led vertically into the socket opening (at a 90-degree angle to the socket). Installing the switch incorrectly can lead to damage or malfunction of the switch. After you have placed the switch in its socket, push very gently on the switch to secure it in place. Make sure that you do not use too much force, as this can damage or destroy fragile components.

Note

Legal Disclaimer

For potential loss of data, especially due to inappropriate handling, Sharkoon assumes no liability.

All named products and descriptions are trademarks and/or registered trademarks of the respective manufacturers and are accepted as protected.

As a continuing policy of product improvement at Sharkoon, the design and specifications are subject to change without prior notice. National product specifications may vary.

All rights reserved especially (also in extracts) for translation, reprinting, reproduction by copying or other technical means. Infringements will lead to compensation. All rights reserved especially in case of assignation of patent or utility patent. Means of delivery and technical modifications reserved.

Disposal of your old products


Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.



When this crossed-out wheeled bin symbol is attached to a product, it means the product is covered by the European Directive 2012/19/EU.

Please be informed about the local separate collection system for electrical and electronic products. Please act according to your local rules and do not dispose of your old products with your normal household waste. The correct disposal of your old product will help prevent potential negative consequences to the environment and human health.

Follow us on social media!



Sharkoon Technologies GmbH

Grüninger Weg 48 35415 Pohlheim Germany

© Sharkoon Technologies 2024

